

Engine Control Module (ECM) I/O Signal

CRUISE CONTROL SYSTEM (DIAGNOSTICS)

4. Engine Control Module (ECM) I/O Signal

A: WIRING DIAGRAM

<Ref. to WI-99, NON-TURBO MODEL, WIRING
DIAGRAM, Cruise Control System.>

<Ref. to WI-102, TURBO MODEL, WIRING DIA-
GRAM, Cruise Control System.>