

19. Sunroof Glass

A: PROCEDURE

For the removal, installation and adjustment method of sunroof glass, refer to the Sunroof section.

- REMOVAL <Ref. to SR-5, REMOVAL, Sunroof Lid.>
- INSTALLATION <Ref. to SR-5, INSTALLATION, Sunroof Lid.>
- ADJUSTMENT <Ref. to SR-5, ADJUSTMENT, Sunroof Lid.>

Sunroof Glass

GLASS/WINDOWS/MIRRORS
