


25. Transmitter

A: DISASSEMBLY

Remove the battery from the keyless transmitter.

NOTE:

Before disassembling the keyless transmitter, prevent damage by static electricity to the transmitter's printed circuit board by touching a steel piece of a building etc. with your hand to discharge any static from your body and clothes.



B: ASSEMBLY


Assemble in the reverse order of disassembly.

C: INSPECTION

Measure the voltage between the battery (+) terminal and (-) terminal.

NOTE:

The battery will discharge during the measurement. Complete the measurement within 5 seconds.



(A) Resistance (47 Ω)

| Tester connection | | Standard |
|----------------------|-----------------|-------------|
| (+) | (-) | |
| Battery (+) terminal | Ground terminal | 2.5 — 3.0 V |

If NG, replace the battery. (Use CR2025 or equivalent.)

D: REPLACEMENT

1. REGISTRATION OF KEYLESS TRANSMITTER WITH SUBARU SELECT MONITOR

NOTE:

- A maximum of four keyless transmitters can be registered for each individual vehicle.
- When replacing or adding a keyless transmitter, new registration of the transmitter is necessary.

- 1) Connect the Subaru Select Monitor to the vehicle.
- 2) Turn the ignition switch to ON.
- 3) From the «Main Menu» on the Subaru Select Monitor, select {2. Check individual system} → {7. Keyless unit mode} → {8. Keyless transmitter ID registration}.
- 4) Input the 8-digit ID number from the left, which is attached to the plastic bag of the keyless transmitter or to the transmitter inner circuit board, then press the [YES] key.

NOTE:

Press the [▲] key on the Subaru Select Monitor to increase the number, and the [▼] key to decrease. Press the [<] key to move to the digit in the left, and [>] to the right.

- 5) The ID number you have entered will be shown. Make sure that the ID number shown is the same as the plastic bag.
- 6) Press the [YES] key if the ID number is correct. If incorrect, press the [NO] key to return to the step 3) and try again.
- 7) «ID registration in process...» is displayed and registration starts.
- 8) «ID registration done» will be displayed when the registration process is done.
- 9) To exit, select «END: NO», and press the [NO] key to return to {8. Keyless transmitter ID registration}. If there are additional keyless transmitters to be registered, select «Next registration: YES», and press the [YES] key to return to the step 3).

NOTE:

- If the registration fails, «ID registration failed. Try again.» will be shown. Press the [YES] key to return to {8. Transmitter ID registration}. And retry from the step 2).
- «END: NO» is shown on the Subaru Select Monitor when fourth keyless transmitter has been registered. Press the [NO] key to return to {8. Keyless transmitter ID registration}.