







15. Cruise Control System

A: WIRING DIAGRAM

1. NON-TURBO MODEL





WI-16152

Cruise Control System

WIRING SYSTEM

C/C(NA)-02

C/C(NA)-02





WI-16153

Cruise Control System

WIRING SYSTEM

C/C(NA)-03

C/C(NA)-03





WI-15022

Cruise Control System

WIRING SYSTEM

2. TURBO MODEL




WI-15023

Cruise Control System

WIRING SYSTEM

C/C(TB)-02

C/C(TB)-02



F44 (BLACK)

1	2	3	4
5	6	7	8

C: i11 (GREEN)

1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	----

B40 (BLACK)

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16

B36

1	2	3	4	5		6	7	8	9	10	11	
12	13	14	15	16	17	18	19	20	21	22	23	24

B: i10 (GREEN)

1	2	3	4	5	6	7		8	9	10	11	12	13	14	
15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30

B38

1	2	3	4				5	6	7	8	9	
10	11	12	13	14	15	16	17	18	19	20	21	
22	23		24	25	26	27	28	29	30		31	32

B: B135 HR

1	2			3	4	5	6	7			
8	9	10	11	12	13	14	15	16	17	18	19
20	21	22	23			24	25			26	27
28	29	30	31			32	33			34	35


C: B136 HR

	1	2	3	4		5	6			
	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27
28	29	30				31	32	33	34	35

WI-16782

Cruise Control System

WIRING SYSTEM



WI-15025