


18.Starter System

A: WIRING DIAGRAM

1. MT MODEL




WI-15028

Starter System


WIRING SYSTEM

2. AT NON-TURBO MODEL



WI-15029

3. AT TURBO MODEL



WI-15030