


Harness Components Location

WIRING SYSTEM

53. Harness Components Location

A: LOCATION



(1) Front wiring harness	(6) Rear door cord RH	(11) Rear gate cord 2
(2) Engine wiring harness	(7) Rear wiring harness	(12) Rear door cord LH
(3) Bulkhead wiring harness	(8) Roof cord	(13) Front door cord LH
(4) Instrument panel wiring harness	(9) Fuel tank cord	(14) Transmission cord
(5) Front door cord RH	(10) Rear gate cord	