

7. Subaru Select Monitor

A: OPERATION

For detailed operation procedures, refer to the “PC application help for Subaru Select Monitor”.

B: INSPECTION

1. COMMUNICATION FOR INITIALIZING THE AIRBAG SYSTEM IS IMPOSSIBLE

DETECTING CONDITION:

Defective harness connector

TROUBLE SYMPTOM:

Communication is impossible between the airbag control module and the Subaru Select Monitor.

NOTE:

Refer to “COMMUNICATION FOR INITIALIZING IMPOSSIBLE” in AIRBAG SYSTEM (DIAGNOSTICS).
<Ref. to AB(diag)-18, COMMUNICATION FOR INITIALIZING IMPOSSIBLE, INSPECTION, Subaru Select Monitor.>

2. COMMUNICATION FOR INITIALIZING ONLY THE OCCUPANT DETECTION SYSTEM IS IMPOSSIBLE

NOTE:

The occupant detection system communicates with the Subaru Select Monitor via the airbag control module.

DETECTING CONDITION:

Defective harness connector between airbag control module and occupant detection control module

TROUBLE SYMPTOM:

Communication is impossible between the airbag control module and the occupant detection control module. Perform the diagnosis from Step 2 in “DTC B1650 OCCUPANT CLASSIFICATION SYSTEM MALFUNCTION”. <Ref. to OD(diag)-19, DTC B1650 OCCUPANT CLASSIFICATION SYSTEM MALFUNCTION, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>