

10. Transmission Control Module (TCM)

A: NOTE

For transmission control module (TCM), refer to “CONTINUOUSLY VARIABLE TRANSMISSION” section.

- Non-turbo model: <Ref. to CVT(TR580)-144, Transmission Control Module (TCM).>
- Turbo model: <Ref. to CVT(TR690)-123, Transmission Control Module (TCM).>