

8. Reduction Drive Gear

A: NOTE

For removal, installation and inspection, refer to
“CVT (TR580)” section. <Ref. to CVT(TR580)-218,
Reduction Drive Gear.>