

1. General Description

A: SPECIFICATION

Specifications for the turbo model are included in the SC(H4DO) section. <Ref. to SC(H4DO)-2, General Description.>

ENGINE (DIAGNOSTICS)

EN(H4DOTC)(diag)

	Page
1. Basic Diagnostic Procedure	2
2. Check List for Interview	4
3. General Description	6
4. Electrical Component Location	9
5. Engine Control Module (ECM) I/O Signal	20
6. Engine Condition Data	30
7. Data Link Connector	31
8. General Scan Tool	32
9. Subaru Select Monitor	37
10. Read Diagnostic Trouble Code (DTC)	44
11. Inspection Mode	45
12. Drive Cycle	48
13. Clear Memory Mode	60
14. System Operation Check Mode	61
15. Malfunction Indicator Light	62
16. Diagnostics for Engine Starting Failure	64
17. List of Diagnostic Trouble Code (DTC)	81
18. Diagnostic Procedure with Diagnostic Trouble Code (DTC)	92
19. Diagnostic Procedure without Diagnostic Trouble Code (DTC)	411
20. General Diagnostic Table	415