

1. General Description

A: SPECIFICATION

Refer to “Body Repair Manual” for general description of body structure, reference points and reference dimensions.

INSTRUMENTATION/DRIVER INFO



	Page
1. General Description	2
2. Relay and Fuse	7
3. Combination Meter System	8
4. Multi-function Display (MFD) System	13
5. Combination Meter	18
6. Speedometer	21
7. Tachometer	22
8. Fuel Gauge	23
9. ECO Gauge	24
10. Multi-function Display (MFD)	25
11. Steering Switch	28