


Electrical Component Location

TIRE PRESSURE MONITORING SYSTEM (DIAGNOSTICS)

3. Electrical Component Location

A: LOCATION



(1) TPMS & keyless entry CM
(model with keyless entry)

(3) Snap-in type transmitter

(4) Tire pressure warning light

(2) TPMS CM
(model with keyless access)

