

7. Transfer Driven Gear

A: NOTE

For removal, installation and inspection, refer to
“CVT (TR580)” or “6MT” section.

CVT (TR580) model:

<Ref. to CVT(TR580)-184, Transfer Driven Gear.>

6MT model:

<Ref. to 6MT-52, Transfer Driven Gear.>