

24. Piston

A: SPECIFICATION

Refer to "Cylinder Block" for removal and installation procedures of pistons. <Ref. to ME(H4DO)-261, REMOVAL, Cylinder Block.> <Ref. to ME(H4DO)-279, INSTALLATION, Cylinder Block.>