


54.Starter System

A: WIRING DIAGRAM

1. NON-TURBO MODEL (WITHOUT PUSH BUTTON START)



WI-45863






Starter System

WIRING SYSTEM

1b

1b


LIST OF CONNECTORS



2. NON-TURBO MODEL (WITH PUSH BUTTON START)

2a

2a



WI-40959


Starter System

WIRING SYSTEM

2b

2b

LIST OF CONNECTORS



WIRING SYSTEM

3a

**WI-391**


Starter System

WIRING SYSTEM

3b

3b

LIST OF CONNECTORS




WI-45865

4. TURBO MODEL (WITH PUSH BUTTON START)

4a

4a



WI-40963

Starter System

WIRING SYSTEM

4b

4b

LIST OF CONNECTORS

