


6. Airbag System

A: WIRING DIAGRAM


1. NON-TURBO MODEL



WI-45661

Airbag System


WIRING SYSTEM



WI-40644

Airbag System

WIRING SYSTEM




WI-45662

Airbag System

WIRING SYSTEM

1d

1d




WI-45663

Airbag System

WIRING SYSTEM

1e

1e



WI-45664


Airbag System

WIRING SYSTEM

1f

1f

LIST OF CONNECTORS




WI-40648

2. TURBO MODEL

2a


2a



WI-45665

Airbag System

WIRING SYSTEM




- | | |
|---|--|
| *1 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2, 3, 6, 7 AND 8 | *4 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 12, 13, 14, 15, 16, 17, 18, 19, 20, 21 AND 22 |
| *2 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 4, 5, 9, 10, 11 AND 12 | |
| *3 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2, 3, 4, 5, 6, 7, 8, 9, 10 AND 11 | *5 : TERMINAL No. OPTIONAL ARRANGEMENT |

WI-40650

Airbag System

WIRING SYSTEM




WI-45666

Airbag System

WIRING SYSTEM

2d

2d




WI-45667

Airbag System

WIRING SYSTEM

2e

2e



WI-45668


Airbag System

WIRING SYSTEM

2f

2f

LIST OF CONNECTORS



WI-40654