


1. NON-TURBO MODEL



Vehicle Dynamics Control System

WIRING SYSTEM




WX : WITH X MODE

*1 : TERMINAL No. OPTIONAL ARRANGEMENT

WI-45880

WIRING SYSTEM




ES : WITH EyeSight

WI-40984

Vehicle Dynamics Control System

WIRING SYSTEM



ES : WITH EyeSight

EM : EXCEPT FOR STANDARD MFD

OG : WITHOUT POWER REAR GATE

WG : WITH POWER REAR GATE

*1 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2, 3, 6, 7 AND 8

*2 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 4, 5, 9, 10, 11 AND 12

*3 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2, 3, 4, 5, 6, 7, 8, 9, 10 AND 11

*4 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 12, 13, 14, 15, 16, 17, 18, 19, 20, 21 AND 22

*5 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2, 3, 4, 5 AND 6


*6 : TERMINAL No. OPTIONAL ARRANGEMENT

WI-40985

1f

1f


LIST OF CONNECTORS



Vehicle Dynamics Control System

WIRING SYSTEM

2. TURBO MODEL



OE : WITHOUT EyeSight


ES : WITH EyeSight

*1 : TERMINAL No. OPTIONAL ARRANGEMENT

WI-40987

Vehicle Dynamics Control System

WIRING SYSTEM




*1 : TERMINAL No. OPTIONAL ARRANGEMENT

WI-45881

Vehicle Dynamics Control System


WIRING SYSTEM



WI-40989

2d

2d




ES : WITH EyeSight

WI-40990

Vehicle Dynamics Control System

WIRING SYSTEM



ES : WITH EyeSight
OG : WITHOUT POWER REAR GATE
WG : WITH POWER REAR GATE

*1 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2, 3, 6, 7 AND 8
*2 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 4, 5, 9, 10, 11 AND 12
*3 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2, 3, 4, 5, 6, 7, 8, 9, 10 AND 11
*4 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 12, 13, 14, 15, 16, 17, 18, 19, 20, 21 AND 22
*5 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2, 3, 4, 5 AND 6
*6 : TERMINAL No. OPTIONAL ARRANGEMENT

WI-40991

2f

2f

LIST OF CONNECTORS

