

70.Instrument Panel Wiring Harness LH

A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
i2	14	★	C-1	R339	Rear wiring harness LH
i5	20	★	B-2		F/B
i10	40	★	A-3		Combination meter
i15	6	★	C-4		Blower fan switch (manual A/C)
i16	16	★	C-4		A/C control panel (manual A/C)
i22	4	★	B-4		Hazard switch
i24	2	★	D-4		Front accessory power supply socket
i28	4	GR	B-1		OP connector (fog light switch)
i29	1	★	C-4		Audio bracket ground
i50	10	★	B-4		Navigation unit
i51	2	★	A-5		Sunload sensor
i55	2	★	C-3		In-vehicle sensor
i79	6	★	B-1		Illumination control switch
i84	35	★	B-1		Body integrated unit
i85	20	★	C-4		Audio
i86	16	★	C-4		Audio
i87	28	★	B-5		Navigation unit
i88	40	★	D-4		A/C control panel (auto A/C)
i101	28	★	C-1	D84	Front door cord LH
i102	18	★	C-1	R167	Rear wiring harness LH
i122	12	B	B-5		MFD
i131	6	★	B-4		Navigation unit
i146	16	★	B-5		
i150	14	★	B-3		Push button ignition switch
i158	2	★	A-2		Side tweeter LH (without audio amplifier)
	4	★	A-2		Side tweeter LH (with audio amplifier)
i166	4	★	B-2		J/C
i167	4	★	B-2		
i171	31	★	B-1		Body integrated unit
i230	18	★	B-2	B552	Bulkhead wiring harness
i231	20	★	B-2	B553	
i234	4	★	B-1		VDC OFF switch
i240	8	B	A-5		MFD
i254	22	★	A-2		J/C
i255	12	★	A-2		
i256	12	★	B-3		
i257	4	★	B-1		Memory height switch
i258	6	★	B-1		VDC OFF & power rear gate driver's switch (with power rear gate)
i259	2	★	D-4		Pocket light
i261	4	★	D-1		J/C
i262	24	★	D-1		Audio amplifier
i263	10	★	D-1		

★ : White or natural color

WIRING SYSTEM

