

7

7

SETTINGS

Bluetooth® SETTINGS

REGISTERING/CONNECTING Bluetooth® DEVICE



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

REGISTERING A Bluetooth PHONE FOR THE FIRST TIME

To use the hands-free system, it is necessary to register a Bluetooth phone with the system.

Once the phone has been registered, it is possible to use the hands-free system.

This operation cannot be performed while driving.

For details about registering a Bluetooth device: →P.182

1. Turn the Bluetooth connection setting of your cellular phone on.
 - This function is not available when Bluetooth connection setting of your cellular phone is set to off.


►Without navigation function

2. Select **PHONE** to display the phone top screen.
 - Operations up to this point can also be performed by pressing the switch on the steering wheel.

►With navigation function

2. Select **HOME** and select **PHONE** (PHONE) to display the phone top screen.
 - Operations up to this point can also be performed by pressing the switch on the steering wheel.
3. Select **Yes** (Yes) to register a phone.

4. When this screen is displayed, search for the device name displayed on this screen on the screen of your Bluetooth device.




- For details about operating the Bluetooth device, see the manual that comes with it.
- To cancel the registration, select **Cancel** (Cancel).

5. Register the Bluetooth device using your Bluetooth device.

- A PIN-code is not required for SSP (Secure Simple Pairing) compatible Bluetooth devices. Depending on the type of Bluetooth device being connected, a message confirming registration may be displayed on the Bluetooth device's screen. Respond and operate the Bluetooth device according to the confirmation message.

►For PBAP compatible Bluetooth phones

6. Select the desired item.




- Yes** (Yes): Transfer contacts from cellular phone.
- No** (No): Do not transfer contacts from cellular phone.

NOTE

- The system waits for connection requests from the registered device.
- At this stage, Bluetooth functions are not yet available.
- If an error message is displayed, follow the guidance on the screen and try again.

7. Select **OK** (OK).

►For OPP compatible Bluetooth phones


6. Select **OK** (OK).

NOTE

- The system waits for connection requests from the registered device.
- If an error message is displayed, follow the guidance on the screen and try again.

7. Select **PHONE**, or select **HOME** and then select **PHONE** (PHONE) to display the telephone top screen.

8. Select the desired item.



- **Transfer** (Transfer): Select to transfer contacts from the connected cellular phone.
- **Add** (Add): Select to add a new contact manually.
- **Cancel** (Cancel): Select to cancel transfer.

REGISTERING A Bluetooth AUDIO DEVICE FOR THE FIRST TIME

To use the Bluetooth Audio, it is necessary to register an audio device with the system.


Once the player has been registered, it is possible to use the Bluetooth Audio.

This operation cannot be performed while driving.

For details about registering a Bluetooth device: →P.182

1. Turn the Bluetooth connection setting of your audio device on.
 - This function is not available when the Bluetooth connection setting of your audio device is set to off.

2. Press the “AUDIO/TUNE” knob.



- The screen can also be displayed by selecting **HOME** followed by **AUDIO** (AUDIO).
- If the audio control screen appears, select **Source** (Source) on the audio screen, or press the “AUDIO/TUNE” knob again.

3. Select **Bluetooth Audio** (Bluetooth Audio).
4. Select **Yes** (Yes) to register an audio device.
5. Follow the steps in “REGISTERING A Bluetooth DEVICE” from “STEP 2”. (→P.182)

PROFILES

This system supports the following services.


Bluetooth Device	Spec.	Function	Requirements	Recommendations
Bluetooth Phone/ Bluetooth Audio Device	Bluetooth Specification	Registering a Bluetooth device	Ver. 1.1	Ver. 3.0 +EDR
Bluetooth Device	Profile	Function	Requirements	Recommendations
Bluetooth Phone	HFP (Hands-Free Profile)	Hands-free system	Ver. 1.0	Ver. 1.6
	OPP (Object Push Profile)	Transferring the contacts	Ver. 1.1	Ver. 1.2
	PBAP (Phone Book Access Profile)		Ver. 1.0	Ver. 1.1
	MAP (Message Access Profile)	Bluetooth phone message	-	Ver. 1.0
	SPP (Serial Port Profile)	APPS function	-	Ver. 1.1
Bluetooth Audio Device	A2DP (Advanced Audio Distribution Profile)	Bluetooth audio system	Ver. 1.0	Ver. 1.2
	AVRCP (Audio/Video Remote Control Profile)		Ver. 1.0	Ver. 1.4

NOTE


- If your cellular phone does not support HFP, registering the Bluetooth phone or using OPP, PBAP, MAP or SPP profiles individually will not be possible.
- If the connected Bluetooth device version is older than recommended or incompatible, the Bluetooth device function may not work properly.

SETTING Bluetooth DETAILS


1. Select **HOME**.



2. Select **SETTINGS** (SETTINGS).
3. Select **Bluetooth** (Bluetooth).
4. Select the desired item to be set.



“Bluetooth Settings (Bluetooth Settings)” SCREEN



Function	Page
Registering a Bluetooth device	182
Deleting a Bluetooth device	183
Connecting a Bluetooth device	184
Editing the Bluetooth device information	186
Bluetooth system settings	188

DISPLAYING THE “Bluetooth Settings (Bluetooth Settings)” SCREEN IN A DIFFERENT WAY

► From the phone/message settings screen

1. Select **HOME**.
2. Select **SETTINGS** (SETTINGS).
3. Select **Phone** (Phone).
4. Select **Connect Phone** (Connect Phone).

► From the status display

1. Select status display area on the screen. (→P.26)

REGISTERING A Bluetooth DEVICE

Up to 5 Bluetooth devices can be registered.

Bluetooth compatible phones (HFP) and audio devices (AVP) can be registered simultaneously.

This operation cannot be performed while driving.

1. Display the “Bluetooth Settings (Bluetooth Settings)” screen. (→P.181)

2. Select **Add** (Add).


► When another Bluetooth device is connected

- To disconnect the Bluetooth device, select **Yes** (Yes).

► When 5 Bluetooth devices have already been registered

- A registered device needs to be replaced. Select **Yes** (Yes), and then select the device to be replaced.

3. When this screen is displayed, search for the device name displayed on this screen on the screen of your Bluetooth device.




- For details about operating the Bluetooth device, see the manual that comes with it.
- To cancel the registration, select **Cancel** (Cancel).

- Register the Bluetooth device using your Bluetooth device.
 - A PIN-code is not required for SSP (Secure Simple Pairing) compatible Bluetooth devices. Depending on the type of Bluetooth device being connected, a message confirming registration may be displayed on the Bluetooth device's screen. Respond and operate the Bluetooth device according to the confirmation message.

- Check that the screen is displayed when registration is complete.
 - The system waits for connection requests coming from the registered device.
 - If a confirmation message appears asking whether to transfer the phone's contact data to the system, select the appropriate button.
 - At this stage, the Bluetooth functions are not yet available.


- Select **OK** (OK) when the connection status changes from "Connection waiting..." (Connection waiting...) to "Connected (Connected)".



- If an error message is displayed, follow the guidance on the screen to try again.

DELETING A Bluetooth DEVICE

- Display the "Bluetooth Settings (Bluetooth Settings)" screen. (→P.181)
- Select **Remove** (Remove).
- Select the desired device.



4. Select **Yes** (Yes) when the confirmation screen appears.
5. Check that a confirmation screen is displayed when the operation is complete.

NOTE

- When deleting a Bluetooth phone, the contact data will be deleted at the same time.


CONNECTING A Bluetooth DEVICE

Up to 5 Bluetooth devices (Phones (HFP) and audio devices (AVP)) can be registered.

If more than 1 Bluetooth device has been registered, select which device to connect to.

1. Display the “Bluetooth Settings (Bluetooth Settings)” screen. (→P.181)

2. Select the device to be connected.



- Supported profile icons will be displayed.
 - : Phone
 - : Audio device
 - : Smartphone Application
- Supported profile icons for currently connected devices will illuminate.
- Dimmed icons can be selected to connect to the phone/audio function directly.
- If the desired Bluetooth device is not on the list, select **Add** (Add) to register the device. (→P.182)

3. Select the desired connection.

►When another Bluetooth device is connected

- To disconnect the Bluetooth device, select **Yes** (Yes).

4. Check that a confirmation screen is displayed when the connection is complete.
 - If an error message is displayed, follow the guidance on the screen to try again.

NOTE

- It may take time if the device connection is carried out during Bluetooth audio playback.
- Depending on the type of Bluetooth device being connected, it may be necessary to perform additional steps on the device.

AUTO CONNECTION MODE

To turn auto connection mode on, set “Bluetooth Power (Bluetooth Power)” to on. (→P.188) Leave the Bluetooth device in a location where the connection can be established.

- When the ignition switch is in the “ACC” or “ON” position, the system searches for a nearby registered device.
- The system will connect with the registered device that was last connected, if it is nearby.

CONNECTING MANUALLY

When the auto connection has failed or “Bluetooth Power (Bluetooth Power)” is turned off, it is necessary to connect Bluetooth manually.

1. Select **[HOME]** and then select **[SETTINGS]** (SETTINGS).
2. Select **[Bluetooth]** (Bluetooth).
3. Follow the steps in “CONNECTING A Bluetooth DEVICE” from “STEP 2”. (→P.184)

RECONNECTING THE Bluetooth PHONE


If a Bluetooth phone is disconnected due to poor reception from the Bluetooth network when the ignition switch is turned to the “ACC” or “ON” position, the system automatically reconnect the Bluetooth phone.

- If a Bluetooth phone is disconnected on purpose, such as turning it off, this does not happen. Reconnect the Bluetooth phone manually.


EDITING THE Bluetooth DEVICE INFORMATION

The Bluetooth device's information can be displayed on the screen. The displayed information can be edited.

1. Display the “Bluetooth Settings (Bluetooth Settings)” screen. (→P.181)
2. Select the desired device to be edited.
3. Select **Device Info** (Device Info).



4. Confirm and change the Bluetooth device information.



No.	Information
1	The name of the Bluetooth device. Can be changed to a desired name. (→P.187)
2	Select to set the Bluetooth audio device connection method. (→P.187)
3	Device address is unique to the device and cannot be changed.
4	Phone number of the Bluetooth phone.

No.	Information
5	Compatibility profile of the Bluetooth device.
6	Select to reset all setup items.

NOTE

- If 2 Bluetooth devices have been registered with the same device name, the devices can be distinguished referring to the device's address.
- Depending on the type of phone, some information may not be displayed.

CHANGING A DEVICE NAME

1. Select **Device Name** (Device Name).
2. Enter the name and then select **OK** (OK).

NOTE

- Even if the device name is changed, the name registered in your Bluetooth device does not change.

SETTING AUDIO DEVICE CONNECTION METHOD

1. Select **Connect Audio Device from** (Connect Audio Device from).
2. Select the desired connection method.
 - **Vehicle** (Vehicle): Select to connect the audio system to the audio device.
 - **Device** (Device): Select to connect the audio device to the audio system.
 - Depending on the audio device, the “Vehicle (Vehicle)” or “Device (Device)” connection method may be best. As such, refer to the manual that comes with the audio device.
 - To reset the connection method, select **Default** (Default).

“System Settings (System Settings)” SCREEN

The Bluetooth settings can be confirmed and changed.

1. Display the “Bluetooth Settings (Bluetooth Settings)” screen. (→P.181)
2. Select **System Settings** (System Settings).
3. Select the desired item to be set.



No.	Information	Page
1	Select to set Bluetooth connection on/off.	189
2	Displays system name. Can be changed to a desired name.	189
3	PIN-code used when the Bluetooth device was registered. Can be changed to a desired code.	189
4	Device address is unique to the device and cannot be changed.	-
5	Select to set the phone connection status display on/off.	-
6	Select to set the connection status display of the audio device on/off.	-
7	Compatibility profile of the system device.	-
8	Select to reset all setup items.	-

CHANGING “Bluetooth Power (Bluetooth Power)”

1. Select **Bluetooth Power** (Bluetooth Power).

■ WHEN “Bluetooth Power (Bluetooth Power)” IS ON

The Bluetooth device is automatically connected when the ignition switch is turned to the “ACC” or “ON” position.

■ WHEN “Bluetooth Power (Bluetooth Power)” IS OFF

The Bluetooth device is disconnected, and the system will not connect to it next time.

NOTE

- While driving, the auto connection state can be changed from off to on, but cannot be changed from on to off.

EDITING THE Bluetooth NAME

1. Select **Bluetooth Name** (Bluetooth Name).
2. Enter a name and then select **OK** (OK).

EDITING THE PIN-CODE


1. Select **Bluetooth PIN** (Bluetooth PIN).
2. Enter a PIN-code and then select **OK** (OK).

OTHER SETTINGS

GENERAL SETTINGS

Settings are available for keyboard layout, operation sounds, etc.

1. Select **HOME**.



2. Select **SETTINGS** (SETTINGS).
3. Select **General** (General).
4. Select the items to be set.

GENERAL SETTINGS SCREEN

General Settings	
Clock	1
Language	2 English >
Units Settings	3 Miles
Beep	4 <input checked="" type="checkbox"/>
Color Theme	5
Default 16	

General Settings	
Keyboard Layout	6 QWERTY >
Auto Change to Split Screen	7 <input checked="" type="checkbox"/>
Animation	8 <input checked="" type="checkbox"/>
Customize Screen Off Image	9
Delete Personal Data	10
Default 16	

General Settings	
aha Settings	11 Bluetooth >
Pandora Settings	12 Bluetooth >
Gracenote® Database Update	13
Software Information	14
Back Camera Delay Control	15 <input checked="" type="checkbox"/>
Default 16	

No.	Function
1 ^{*1}	Select to change the vehicle clock settings. (→P.192)
2	Select to change the language.
3	Select to change the unit for measuring distance.
4	Select to turn the beep sound on/off.
5	Select to change the button and screen color.
6	Select to change the keyboard layout.
7	Select to turn on/off the setting that returns the display to the split screen automatically after 20 seconds when a screen other than the split screen is displayed.
8	Select to turn the animation function on/off.
9	Select to customize the screen off image. (→P.194)
10	Select to delete personal data. (→P.195)
11	Select to set the connected device when using aha. Select USB (USB) when using an iPhone, and then select Bluetooth (Bluetooth) when using Android devices.

No.	Function
12	Select to set the connected device when using Pandora ^{*2} . Select USB (USB) when using an iPhone, and then select Bluetooth (Bluetooth) when using Android devices.
13	Select to update the Gracenote® database. For details, contact your SUBARU dealer.
14	Select to display the software information. Notices related to third party software used in this product are enlisted. (This includes instructions for obtaining such software, where applicable.)
15	Select to set the back camera delay control on/off. When set to on, the back camera image displays for approximately 6 seconds after moving the shift lever/ select lever “R” to any position other than “R”. The display disappears when the shift lever/ select lever is moved to “P”, or when the vehicle speed reaches approximately 5 mph (8 km/h) or faster.
16	Select to reset all setup items.

*1: With navigation function

*2: Pandora is available in the United States, Australia, and New Zealand.

CLOCK SETTINGS (WITH NAVIGATION FUNCTION)

Used to set the auto update setting for time zones, daylight saving time and automatic time adjustment on/off.

1. Display the “General Settings (General Settings)” screen. (→P.190)
2. Select **Clock** (Clock).
3. Select the items to be set.



No.	Function
1	Select to change the time zone. (→P.192)
2	Select to set daylight saving time on/off or to auto. When set to auto, the daylight saving time setting automatically turns on or off based on the current location information.

4. Select **OK** (OK).

■ SETTING THE TIME ZONE

1. Select **Time Zone** (Time Zone).
2. Select the desired time zone.



CUSTOMIZING THE SCREEN OFF IMAGES

When the screen is turned off, the desired set image can be displayed as the screen off image. Images can be copied from a USB memory or SD card*. A USB memory or SD card* must be connected when editing screen off images. (→P.41, 42)

*: With navigation function

NOTE

- When saving the images to a USB or SD card* name the folder that the screen off image is saved to “Image”. If this folder name is not used, the system cannot download the images. (The folder name is case sensitive.)
- *: With navigation function
- Image files saved to the map SD card cannot be played.

■ TRANSFERRING IMAGES

1. Select **HOME**.
2. Select **SETTINGS** (SETTINGS).
3. Select **General** (General).
4. Select **Customize Screen Off Image** (Customize Screen Off Image).
5. Select the device that the image is stored on.
6. Select **Copy from [device]** (Copy from [device]).

7. Select the desired images from the list and then select **Copy** (Copy).




- The selected image is displayed on the right side of the screen. If the selected image file is broken or incompatible,  will be displayed.
- The remaining number of image files that can be transferred is displayed at the bottom of the screen.
- 8. Select **Yes** (Yes) when the confirmation screen appears.

NOTE

- **Copy from [device]** (Copy from [device]) : [device] will automatically be filled in with the name of the selected device.
- The compatible file extensions are JPG and JPEG.
- Image files of 10 MB or less can be transferred.
- Up to 10 images can be downloaded.
- Files with non-ASCII filenames can not be downloaded.

■ SETTINGS THE SCREEN OFF IMAGES


1. Display the “General Settings (General Settings)” screen. (→P.190)
2. Select **Customize Screen Off Image** (Customize Screen Off Image).
3. Select the device that the image is stored on.
4. Select **Select Images** (Select Images).
5. Select the desired image.



6. Select **OK** (OK).

■ DELETING TRANSFERRED IMAGES


1. Display the “General Settings (General Settings)” screen. (→P.190)
2. Select **Customize Screen Off Image** (Customize Screen Off Image).
3. Select the device that the image is stored on.
4. Select **Delete Images** (Delete Images).
5. Select the images to be deleted and then select **Delete** (Delete).



6. Select **Yes** (Yes) when the confirmation screen appears.

DELETING PERSONAL DATA

1. Display the “General Settings (General Settings)” screen. (→P.190)
2. Select **Delete Personal Data** (Delete Personal Data).
3. Select **Delete** (Delete).



4. Select **Yes** (Yes) when the confirmation screen appears.

- Registered or changed personal settings will be deleted or returned to their default conditions.

For example:

- Navigation settings*
- Audio settings
- SiriusXM Radio settings
- SiriusXM Radio service contents
- Phone settings

*: With navigation function


CAUTION

- With navigation function: Make sure the map SD card is inserted when deleting personal data. The personal data cannot be deleted when the map SD card is removed. To delete the data, after inserting the map SD card, turn the ignition switch to the “ACC” or “ON” position.

VOICE SETTINGS

Voice volume, etc. can be set.

1. Select **HOME**.



2. Select **SETTINGS** (SETTINGS).
3. Select **Voice** (Voice).
4. Select the items to be set.

NOTE

- “Voice Settings (Voice Settings)” screen can also be displayed from the voice recognition top screen. (→P.252)

VOICE SETTINGS SCREEN



No.	Function
1	Select to adjust the volume of voice guidance.
2	Select to mute/unmute the navigation voice guidance.
3	Select to set the voice recognition prompts.
4	Select to reset all setup items.

NOTE

- The volume can even be adjusted by turning the “**POWER/VOLUME**” knob or by pressing the “+/-” steering switches (→P.96) during voice guidance.