

2. Front Speaker S901466

A: REMOVAL S901466A18

- 1) Remove front door trim and disconnect connector. <Ref. to EI-22 REMOVAL, Door Trim.>
- 2) Remove screws which secure front speaker.
- 3) Remove speaker and disconnect connector.

B: INSTALLATION S901466A11

Install in the reverse order of removal.