


4. Electrical Components Location S006507

A: LOCATION S006507A13










H4M1390A

- (1) ABS control module and hydraulic control unit (ABSCM&H/U)
- (2) Proportioning valve
- (3) Diagnosis connector
- (4) ABS warning light

- (5) Data link connector (for Subaru select monitor)
- (6) Automatic transmission control module
- (7) Tone wheel

- (8) ABS sensor
- (9) Wheel cylinder
- (10) G sensor
- (11) Brake switch
- (12) Master cylinder

 B4M1226B	 H4M1304A	 S4M0055A
FRONT  B4M2201C	REAR  B4M0646G	 B4M0231E
 S4M0056A	SUBARU.	SUBARU.