

14. Compulsory Valve Operation Check Mode

S008528

2) Connect diagnosis cable to Subaru Select Monitor.


A: OPERATION

S008528A16

1. SUBARU SELECT MONITOR

S008528A1601

- 1) Prepare Subaru Select Monitor kit.



- A list of the support data is shown in the following table.

Contents	Display
Compulsory fuel pump relay operation check	Fuel Pump Relay
Compulsory radiator fan relay operation check	Radiator Fan Relay
Compulsory air conditioning relay operation check	A/C Relay
Compulsory pressure control solenoid valve operation check	PCV Solenoid Valve
Compulsory drain valve operation check	Vent Control Solenoid Valve

NOTE:

- Because ASV solenoid valve, FICD solenoid valve and air injection system diagnosis solenoid valve are not installed, ASV Solenoid Valve, FICD Solenoid Valve and Pressure Switching Sol.2 will be displayed but non-functional.
- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

COMPULSORY VALVE OPERATION CHECK MODE

Engine

MEMO: