

11. Read Diagnostic Trouble Code

A: OPERATION

S008508A16

1. SUBARU SELECT MONITOR (NORMAL MODE)

S008508A1601

- 1) On the 「Main Menu」 display screen, select the {Each System Check} and press the [YES] key.
- 2) On the 「System Selection Menu」 display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the 「Engine Diagnosis」 display screen, select the {Diagnostic Code(s) Display} and press the [YES] key.
- 5) On the 「Diagnostic Code(s) Display」 display screen, select the {Current Diagnostic Code(s)} or {History Diagnostic Code(s)} and press the [YES] key.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For detailed concerning diagnostic trouble codes, refer to the "List of Diagnostic Trouble Code (DTC)".
 - 2200 cc models: <Ref. to EN-93 LIST, List of Diagnostic Trouble Code (DTC) for 2200 cc Models.>
 - 2500 cc models: <Ref. to EN-300 LIST, List of Diagnostic Trouble Code (DTC) for 2500 cc Models.>

2. SUBARU SELECT MONITOR (OBD MODE)

S008508A1602

- 1) On the 「Main Menu」 display screen, select the {Each System Check} and press the [YES] key.
- 2) On the 「System Selection Menu」 display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the 「Engine Diagnosis」 display screen, select the {OBD System} and press the [YES] key.
- 5) On the 「OBD Menu」 display screen, select the {Diagnosis Code(s) Display} and press the [YES] key.
- 6) Make sure that a diagnostic trouble code (DTC) is shown on the display screen.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

- For detailed concerning diagnostic trouble codes, refer to the "List of Diagnostic Trouble Code (DTC)".

- 2200 cc models: <Ref. to EN-93 LIST, List of Diagnostic Trouble Code (DTC) for 2200 cc Models.>
- 2500 cc models: <Ref. to EN-300 LIST, List of Diagnostic Trouble Code (DTC) for 2500 cc Models.>

3. OBD-II GENERAL SCAN TOOL

S008508A1603

Refers to data denoting emission-related powertrain diagnostic trouble codes.

For details concerning diagnostic trouble codes, refer to the "List of Diagnostic Trouble Code (DTC)".

- 2200 cc models: <Ref. to EN-93 LIST, List of Diagnostic Trouble Code (DTC) for 2200 cc Models.>
- 2500 cc models: <Ref. to EN-300 LIST, List of Diagnostic Trouble Code (DTC) for 2500 cc Models.>

NOTE:

Refer to OBD-II general scan tool manufacturer's instruction manual to access emission-related powertrain diagnostic trouble codes (MODE \$03).