

# BASIC DIAGNOSTICS PROCEDURE

Airbag System

## 1. Basic Diagnostics Procedure

S002627

### A: PROCEDURE S002627E45

No.	Step	Check	Yes	No
1	<b>Read Diagnostics Trouble Code.</b> <Ref. to AB-19 OPERATION, Read Diagnostics Trouble Code.>	Is the normal code being detected?	Finish the diagnosis.	Go to step 2.
2	<b>Read Diagnostics Trouble Code.</b> <Ref. to AB-19 OPERATION, Read Diagnostics Trouble Code.>	Is the trouble code being detected?	Go to step 3.	Go to "Air bag Warning Light Illumination Pattern". <Ref. to AB-23 INSPECTION, Air bag Warning Light Illumination Pattern.>
3	<b>Perform the diagnosis.</b> 1) Judge the possible cause from "List of Diagnostic Trouble Code". <Ref. to AB-22 LIST, List of Diagnostic Trouble Code.> 2) Inspect using "Diagnostic Chart with Trouble Code". (DTC) <Ref. to AB-22 LIST, List of Diagnostic Trouble Code.> 3) Repair the cause of the trouble. 4) Perform the clear memory mode. <Ref. to AB-21 OPERATION, Clear Memory Mode.> 5) Perform the inspection mode. <Ref. to AB-20 OPERATION, Inspection Mode.> 6) Read diagnostics trouble code.<Ref. to AB-19 OPERATION, Read Diagnostics Trouble Code.>	Is the trouble code being detected?	Perform the procedure 1) to 5) in step 3.	Finish the diagnosis.