

**2. Radio System****A: SCHEMATIC****1. RADIO**

<Ref. to WI-54, SCHEMATIC, Audio System.>

# RADIO SYSTEM

## ENTERTAINMENT

### B: INSPECTION

Symptom	Repair order
No power coming in (No display and no sound from speakers)	(1) Check fuse and power supply for radio. (2) Check radio ground. (3) Remove radio for repair.
A specific speaker does not operate.	(1) Check speaker. (2) Check output circuit between radio and speaker.
Radio generates noise with engine running	(1) Check radio ground. (2) Check generator. (3) Check ignition coil. (4) Remove radio for repair.
AM and FM modes are weak or noisy	(1) Check antenna. (2) Check radio ground. (3) Remove radio for repair.