


8. Antenna

A: REMOVAL

- 1) Remove the mounting screws and detach antenna.
- 2) Disconnect the harness connector.



B: INSTALLATION

Install in the reverse order of removal.