


9. Roof Spoiler

A: REMOVAL

- 1) Remove the bolt cap, then remove the two bolts.
- 2) Detach the roof spoiler.



B: INSTALLATION

Install in the reverse order of removal.