

### 13. Transfer Duty Solenoid and Valve Body

#### A: NOTE

For removal, installation and inspection work, refer to "AT" section. <Ref. to AT-64, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>