

### 3. Transfer Clutch and Extension for AT

#### A: NOTE

For removal, installation and inspection work, refer to "AT" section.<Ref. to AT-83, Transfer Clutch.>