

## **14. Clear Memory Mode**

### **A: OPERATION**

#### **1. SUBARU SELECT MONITOR (NORMAL MODE)**

- 1) On the «Main Menu» display screen, select {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after the engine type information is displayed.
- 4) On the «Engine Diagnosis» display screen, select {Clear Memory} and press the [YES] key.
- 5) When “Done” and “Turn Ignition Switch OFF” are shown on the display screen, turn the Subaru Select Monitor and ignition switch to OFF.

**NOTE:**

- For detailed operation procedures, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

#### **2. SUBARU SELECT MONITOR (OBD MODE)**

- 1) On the «Main Menu» display screen, select {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after the engine type information is displayed.
- 4) On the «Engine Diagnosis» display screen, select {OBD System} and press the [YES] key.
- 5) On the «OBD Menu» display screen, select {4. Diagnosis Code(s) Cleared} and press the [YES] key.
- 6) When “Clear Diagnostic Code?” is shown on the display screen, press the [YES] key.
- 7) Turn the Subaru Select Monitor and ignition switch to OFF.

**NOTE:**

- For detailed operation procedures, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

#### **3. OBD-II GENERAL SCAN TOOL**

For clear memory procedures using the OBD-II general scan tool, refer to the OBD-II General Scan Tool Instruction Manual.