


## 6. Mud Guard

### A: REMOVAL


#### 1. FRONT MUD GUARD

- 1) Jack-up the vehicle.
- 2) Remove the front wheels.
- 3) Remove the screws and clips to remove the mud guard.



#### 2. REAR MUD GUARD

- 1) Jack-up the vehicle.
- 2) Remove the rear wheels.
- 3) Remove the screws and clips to remove the mud guard.



(1) Rear mud guard RH

(2) Rear mud guard LH

### B: INSTALLATION

Install in the reverse order of removal.