

1. General Description

A: SPECIFICATION

Specifications for the turbo model are included in the "SC(H4SO)" section. <Ref. to SC(H4SO)-2, General Description.>

ENGINE (DIAGNOSTICS)

EN(H4DOTC)(diag)

	Page
1. Basic Diagnostic Procedure	2
2. Check List for Interview	4
3. General Description	6
4. Electrical Component Location	9
5. Engine Control Module (ECM) I/O Signal	18
6. Engine Condition Data	29
7. Data Link Connector	30
8. General Scan Tool	31
9. Subaru Select Monitor	36
10. Read Diagnostic Trouble Code (DTC)	44
11. Inspection Mode	45
12. Drive Cycle	50
13. Clear Memory Mode	56
14. Compulsory Valve Operation Check Mode	57
15. System Operation Check Mode	58
16. Malfunction Indicator Light	60
17. Diagnostics for Engine Starting Failure	70
18. Diagnostic Procedure for Subaru Select Monitor Communication	83
19. List of Diagnostic Trouble Code (DTC)	85
20. Diagnostic Procedure with Diagnostic Trouble Code (DTC)	93
21. General Diagnostic Table	386