

## **Clear Memory Mode**

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

---

### **9. Clear Memory Mode**

#### **A: OPERATION**

Refer to "Subaru Select Monitor" for information about how to clear a DTC.

<Ref. to 4AT(diag)-18, CLEAR MEMORY MODE, OPERATION, Subaru Select Monitor.>