


48. Cruise Control System

A: WIRING DIAGRAM


1. NON-TURBO MODEL



WI-22151

Cruise Control System








WIRING SYSTEM



WI-27938


C/C(NA)-03

C/C(NA)-03



Cruise Control System

WIRING SYSTEM





WI-27939

2. TURBO MODEL

C/C(TB)-01


C/C(TB)-01



WI-22152

Cruise Control System

WIRING SYSTEM




WI-27940

Cruise Control System

WIRING SYSTEM

C/C(TB)-03

C/C(TB)-03



(i97) (BLACK)

1	2	3	4	5	6	7	8
---	---	---	---	---	---	---	---

A: (B134)

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31	32	33	34	

B: (B135)

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31	32	33	34	35

(B220)

1	2	9	13	17	21
3	4	10	14	18	22
5	6	11	15	19	23
7	8	12	16	20	24
25	29	33	37		
26	30	34	38		
27	28	31	32	35	36
39	40				

RELAY BLOCK

C: (B136)

1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24
25	26	27	28	29	30
31	32	33	34	35	

(i10)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

WI-27028

Cruise Control System

WIRING SYSTEM

