

10. Clear Memory Mode

A: OPERATION

For operation procedures, refer to the “PC application help for Subaru Select Monitor”.

NOTE:

Clear the DTC stored in the airbag control module after repairing the airbag system.