

1. General Description

A: SPECIFICATION

Refer to “Body Repair Manual” for general description of body structure, reference points and reference dimensions.

INSTRUMENTATION/DRIVER INFO



	Page
1. General Description	2
2. Relay and Fuse	5
3. Combination Meter System	6
4. Multi-function Display (MFD) System	10
5. Combination Meter	15
6. Speedometer	18
7. Tachometer	19
8. Fuel Gauge	20
9. ECO Gauge	21
10. Multi-function Display (MFD)	22
11. Steering Switch	25