


Electrical Component Location

IMMOBILIZER (DIAGNOSTICS)

3. Electrical Component Location

A: LOCATION



IM-00393

- | | | |
|---|--------------------------|--|
| (1) Antenna | (3) Body integrated unit | (5) Security control module (only for Canada models) |
| (2) Security indicator light (LED bulb) | (4) Transponder | |