


Electrical Component Location

POWER ASSISTED SYSTEM (POWER STEERING) (DIAGNOSTICS)

4. Electrical Component Location

A: LOCATION




PS-01292


- | | | |
|---|---------------------------------------|---|
| (1) Steering gearbox | (4) STEERING warning light (C0 model) | (7) Data link connector (For Subaru Select Monitor) |
| (2) Power steering control module | (5) Engine control module (ECM) | |
| (3) STEERING warning light (U5, U6 model) | (6) VDCCM&H/U | |

Electrical Component Location


POWER ASSISTED SYSTEM (POWER STEERING) (DIAGNOSTICS)




PS-01290




PS-01242




PS-01296




PS-01297



PS-01305



PS-01293



PS-01294

SUBARU.