

**17. Brake Fluid****A: INSPECTION**

Refer to "BR" section for brake fluid inspection.  
<Ref. to BR-55, INSPECTION, Brake Fluid.>

**B: REPLACEMENT**

Refer to "BR" section for brake fluid replacement.  
<Ref. to BR-55, REPLACEMENT, Brake Fluid.>