

6. V-belt

A: INSPECTION

Refer to "ME" section for V-belt inspection. <Ref. to ME(H4DO)-77, V-belt.>

B: REPLACEMENT

Refer to "ME" section for V-belt replacement. <Ref. to ME(H4DO)-77, V-belt.>