


Electrical Component Location

OCCUPANT DETECTION SYSTEM (DIAGNOSTICS)

4. Electrical Component Location

A: LOCATION



- | | | |
|---------------------------------------|-----------------------------------|--------------------------------------|
| (1) Occupant detection control module | (3) Airbag ON/OFF indicator light | (4) Buckle switch (passenger's seat) |
| (2) Occupant detection sensor | | |