



7. Scalp Cap

A: REPLACEMENT

- 1) Remove the mirror. <Ref. to GW-19, REPLACEMENT, Outer Mirror.>
- 2) Press-in the clips (A) from inside of outer mirror.



- 3) Pull the scalp cap away from the outer mirror, release upper side clips (A), and then remove the scalp cap.



- 4) Install the scalp cap securely.