

### **8. Clear Memory Mode**

#### **A: OPERATION**

For details concerning DTC clear operation, refer to "Subaru Select Monitor". <Ref. to LAN(diag)-22, CLEAR MEMORY MODE, OPERATION, Subaru Select Monitor.>