

22.Rear Side Marker Light Bulb

A: REMOVAL


NOTE:

Equipped with 5 door model only.

1) Remove the rear combination light assembly.

<Ref. to LI-25, 5 DOOR MODEL, REMOVAL, Rear Combination Light Assembly.>

2) Turn the socket and remove the bulb.



B: INSTALLATION

Install each part in the reverse order of removal.

C: INSPECTION

1) Visually check the bulb for blow out.

2) Check the bulb specification. <Ref. to LI-2, SPECIFICATION, General Description.>

3) Replace the bulb if it is found defective.