



36.Combination Meter System

A: WIRING DIAGRAM

1. WITHOUT SI-DRIVE






WI-42474

Combination Meter System

WIRING SYSTEM



WI-33819

C/M-04

C/M-04


ON

: WITHOUT NAVIGATION

WN


: WITH NAVIGATION

*1 : SEAT BELT
KEY WARNING
HEADLIGHT ON WARNING
CUSTOMIZED



Combination Meter System

WIRING SYSTEM




WI-33821

2. WITH SI-DRIVE

C/M(S)-01


C/M(S)-01



WI-30468

Combination Meter System


WIRING SYSTEM



WI-42475

Combination Meter System

WIRING SYSTEM



WI-33823


Combination Meter System

WIRING SYSTEM

C/M(S)-04

C/M(S)-04


ON	: WITHOUT NAVIGATION
WN	: WITH NAVIGATION
*1	: SEAT BELT KEY WARNING HEADLIGHT ON WARNING DCCD REV. CUSTOMIZED SI-DRIVE



WI-33824

Combination Meter System

WIRING SYSTEM



WI-33825