

### 7. Read Diagnostic Trouble Code (DTC)

#### A: OPERATION

For detailed operation procedures, refer to “PC application help for Subaru Select Monitor”.