

### 7. Read Diagnostic Trouble Code (DTC)

#### A: OPERATION

For operation procedures, refer to the “PC application help for Subaru Select Monitor”.