


3. Fuse And Relay

A: LOCATION

1. ENGINE TYPE FA (WITHOUT PUSH BUTTON START, ENGINE COMPARTMENT SIDE)

1a

1a






- (1) HORN RELAY
- (2) REAR DEFOGGER RELAY
- (3) MAIN FAN RELAY 1
- (4) HEADLIGHT RELAY LO
- (5) HEADLIGHT RELAY HI

- (6) DAYTIME RUNNING LIGHT RELAY
- (7) SUB FAN RELAY
- (8) A/C RELAY
- (9) MAIN FAN RELAY 2
- (10) BRAKE PUMP RELAY
- (11) FUEL INJECTOR RELAY


2. ENGINE TYPE FA (WITHOUT PUSH BUTTON START, PASSENGER ROOM SIDE)

2a

2a



B225 RELAY HOLDER



B220 RELAY HOLDER

- (1) IG 2 RELAY
- (2) ACCESSORY RELAY
- (3) STARTER RELAY 1
- (4) POWER WINDOW RELAY
- (5) TAIL & ILLUMINATION RELAY
- (6) ELECTRONIC THROTTLE CONTROL RELAY
- (7) A/F, OXYGEN SENSOR RELAY

- (8) FUEL PUMP RELAY
- (9) IG RELAY
- (10) MAIN RELAY
- (11) SELF SHUT RELAY
- (12) FRONT FOG LIGHT RELAY
- (13) WIPER DEICER RELAY
- (14) SEAT HEATER RELAY

WI-44239


Fuse And Relay

WIRING SYSTEM

3. ENGINE TYPE FA (WITH PUSH BUTTON START, ENGINE COMPARTMENT SIDE)

3a

3a



- (1) HORN RELAY
- (2) REAR DEFOGGER RELAY
- (3) MAIN FAN RELAY 1
- (4) HEADLIGHT RELAY LO
- (5) HEADLIGHT RELAY HI





- (6) DAYTIME RUNNING LIGHT RELAY
- (7) SUB FAN RELAY
- (8) A/C RELAY
- (9) MAIN FAN RELAY 2
- (10) BRAKE PUMP RELAY
- (11) FUEL INJECTOR RELAY

WI-44240

4. ENGINE TYPE FA (WITH PUSH BUTTON START, PASSENGER ROOM SIDE)

4a

4a



- (1) IG 2 RELAY
- (2) ACCESSORY RELAY
- (3) STARTER RELAY 1
- (4) POWER WINDOW RELAY
- (5) TAIL & ILLUMINATION RELAY
- (6) ELECTRONIC THROTTLE CONTROL RELAY
- (7) A/F, OXYGEN SENSOR RELAY
- (8) STARTER RELAY (PUSH BUTTON START)
- (9) IG RELAY 2

- (10) IG RELAY 1
- (11) STARTER CUT RELAY
- (12) FUEL PUMP RELAY
- (13) IG RELAY
- (14) MAIN RELAY
- (15) SELF SHUT RELAY
- (16) FRONT FOG LIGHT RELAY
- (17) WIPER DEICER RELAY
- (18) SEAT HEATER RELAY

WI-44241


Fuse And Relay

WIRING SYSTEM

5. ENGINE TYPE EJ (WITHOUT PUSH BUTTON START, ENGINE COMPARTMENT SIDE)

5a

5a



- (1) HORN RELAY
- (2) REAR DEFOGGER RELAY
- (3) MAIN FAN RELAY 1
- (4) HEADLIGHT RELAY LO
- (5) HEADLIGHT RELAY HI
- (6) DAYTIME RUNNING LIGHT RELAY




- (7) SUB FAN RELAY
- (8) A/C RELAY
- (9) MAIN FAN RELAY 2
- (10) AIR CUT RELAY 1
- (11) AIR CUT RELAY 2
- (12) AIR PUMP RELAY

WI-44242


6. ENGINE TYPE EJ (WITHOUT PUSH BUTTON START, PASSENGER ROOM SIDE)

6a

6a



B225 RELAY HOLDER



B220 RELAY HOLDER

- | | |
|---------------------------------------|----------------------------|
| (1) IG 2 RELAY | (8) FUEL PUMP RELAY |
| (2) ACCESSORY RELAY | (9) MAIN RELAY |
| (3) STARTER RELAY 1 | (10) DCCD RELAY |
| (4) POWER WINDOW RELAY | (11) FRONT FOG LIGHT RELAY |
| (5) TAIL & ILLUMINATION RELAY | (12) WIPER DEICER RELAY |
| (6) ELECTRONIC THROTTLE CONTROL RELAY | (13) SEAT HEATER RELAY |
| (7) A/F, OXYGEN SENSOR RELAY | |

WI-44243


Fuse And Relay

WIRING SYSTEM

7. ENGINE TYPE EJ (WITH PUSH BUTTON START, ENGINE COMPARTMENT SIDE)

7a

7a



- (1) HORN RELAY
- (2) REAR DEFOGGER RELAY
- (3) MAIN FAN RELAY 1
- (4) HEADLIGHT RELAY LO
- (5) HEADLIGHT RELAY HI
- (6) DAYTIME RUNNING LIGHT RELAY





- (7) SUB FAN RELAY
- (8) A/C RELAY
- (9) MAIN FAN RELAY 2
- (10) AIR CUT RELAY 1
- (11) AIR CUT RELAY 2
- (12) AIR PUMP RELAY

WI-44244

8. ENGINE TYPE EJ (WITH PUSH BUTTON START, PASSENGER ROOM SIDE)

8a

8a



- | | |
|---------------------------------------|----------------------------|
| (1) IG 2 RELAY | (10) IG RELAY 1 |
| (2) ACCESSORY RELAY | (11) STARTER CUT RELAY |
| (3) STARTER RELAY 1 | (12) FUEL PUMP RELAY |
| (4) POWER WINDOW RELAY | (13) MAIN RELAY |
| (5) TAIL & ILLUMINATION RELAY | (14) DCCD RELAY |
| (6) ELECTRONIC THROTTLE CONTROL RELAY | (15) FRONT FOG LIGHT RELAY |
| (7) A/F, OXYGEN SENSOR RELAY | (16) WIPER DEICER RELAY |
| (8) STARTER RELAY (PUSH BUTTON START) | (17) SEAT HEATER RELAY |
| (9) IG RELAY 2 | |

WI-44245