

18. Brake Fluid

A: INSPECTION

Refer to "BR" section for brake fluid inspection. <Ref. to BR-64, INSPECTION, Brake Fluid.>

B: REPLACEMENT

Refer to "BR" section for brake fluid replacement. <Ref. to BR-64, REPLACEMENT, Brake Fluid.>