

9. Oil Catch Tank

A: REMOVAL

Refer to "Oil Catch Tank" for removal procedure of the oil catch tank. <Ref. to IN(w/o STI)-52, REMOVAL, Oil Catch Tank.>

B: INSTALLATION

Refer to "Oil Catch Tank" for installation procedure of the oil catch tank. <Ref. to IN(w/o STI)-53, INSTALLATION, Oil Catch Tank.>

C: INSPECTION

Refer to "Oil Catch Tank" for inspection procedure of the oil catch tank. <Ref. to IN(w/o STI)-56, INSPECTION, Oil Catch Tank.>